

# Aspire Series Service Guide

Service guide files and updates are available on the ACER/CSD web; for more information, please refer to <http://csd.acer.com.tw>

PRINTED IN TAIWAN

---

## Revision History

Please refer to the table below for the updates made on this service guide.

| Date | Chapter | Updates |
|------|---------|---------|
|      |         |         |
|      |         |         |
|      |         |         |

---

## Copyright

Copyright © 2010 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

## Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation.

Intel is a registered trademark of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

---

## Conventions

The following conventions are used in this manual:

|                        |  |
|------------------------|--|
| <b>SCREEN MESSAGES</b> | Denotes actual messages that appear on screen.                                       |
| <b>NOTE</b>            | Gives bits and pieces of additional information related to the current topic.        |
| <b>WARNING</b>         | Alerts you to any damage that might result from doing or not doing specific actions. |
| <b>CAUTION</b>         | Gives precautionary measures to avoid possible hardware or software problems.        |
| <b>IMPORTANT</b>       | Reminds you to do specific actions relevant to the accomplishment of procedures.     |



**NOTE:** This symbol where placed in the Service Guide designates a component that should be recycled according to the local regulations.

---

## Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.



|  |               |
|--|---------------|
| <b>System Specifications</b>                   | <b>1</b>      |
| Features                                       | 1             |
| System Block Diagram                           | 4             |
| Notebook Tour                                  | 5             |
| Top View                                       | 5             |
| Closed Front View                              | 6             |
| Left View                                      | 6             |
| Right View                                     | 7             |
| Base View                                      | 8             |
| Indicators                                     | 8             |
| TouchPad Basics                                | 9             |
| Using the Keyboard                             | 10            |
| Lock Keys and embedded numeric keypad          | 10            |
| Windows Keys                                   | 11            |
| Hot Keys                                       | 12            |
| Special Keys                                   | 13            |
| Hardware Specifications and Configurations     | 14            |
| <br><b>System Utilities</b>                    | <br><b>19</b> |
| BIOS Setup Utility                             | 19            |
| Navigating the BIOS Utility                    | 19            |
| Information                                    | 20            |
| Main   | 21            |
| Security                                       | 22            |
| Boot   | 25            |
| Exit   | 26            |
| BIOS Flash Utility                             | 27            |
| DOS Flash Utility                              | 27            |
| WinFlash Utility                               | 28            |
| Remove HDD/BIOS Password Utilities             | 29            |
| Removing BIOS Passwords:                       | 30            |
| Miscellaneous Utilities                        | 31            |
| <br><b>Machine Disassembly and Replacement</b> | <br><b>33</b> |
| Disassembly Requirements                       | 33            |
| Related Information                            | 33            |
| Replacement Requirements                       | 33            |
| Pre-disassembly Instructions                   | 34            |
| Disassembly Process                            | 35            |
| External Module Disassembly Process            | 36            |
| External Modules Disassembly Flowchart         | 36            |
| Removing the Battery Pack                      | 37            |
| Removing the Dummy Card                        | 38            |
| Removing the Base Door                         | 39            |
| Removing the Hard Disk Drive Module            | 40            |
| Removing the DIMM Module                       | 42            |
| Removing the WLAN Module                       | 43            |
| Removing the 2nd HDD Module                    | 45            |
| Removing the ODD Module                        | 48            |
| Main Unit Disassembly Process                  | 50            |
| Main Unit Disassembly Flowchart                | 50            |
| Removing the Keyboard                          | 52            |
| Removing the Upper Cover                       | 54            |
| Removing the LCD Module                        | 56            |

# Table of Contents

|                                   |     |
|-----------------------------------|-----|
| Removing the Bluetooth Module     | 58  |
| Removing the USB Board            | 60  |
| Removing the Mainboard            | 62  |
| Removing the LAN Board            | 64  |
| Removing the RTC Battery          | 65  |
| Removing the Thermal Module       | 66  |
| Removing the CPU                  | 68  |
| Removing the PCH Heatsink         | 69  |
| Removing the DC-IN Cable Assembly | 70  |
| Removing the Switch Board         | 71  |
| Removing the Power Board          | 73  |
| LCD Module Disassembly Process    | 75  |
| LCD Module Disassembly Flowchart  | 75  |
| Removing the LCD Bezel            | 76  |
| Removing the Camera Board         | 78  |
| Removing the LCD Panel            | 79  |
| Removing the Antennas             | 83  |
| LCD Reassembly Procedure          | 85  |
| Replacing the Microphone          | 85  |
| Replacing the Antennas            | 86  |
| Replacing the LCD Panel           | 88  |
| Replacing the Camera Board        | 92  |
| Replacing the LCD Bezel           | 93  |
| Main Unit Reassembly Process      | 95  |
| Replacing the Power Assembly      | 95  |
| Replacing the PCH Thermal Module  | 96  |
| Replacing the CPU                 | 96  |
| Replacing the Thermal Module      | 98  |
| Replacing the RTC Battery         | 99  |
| Removing the LAN Board            | 100 |
| Replacing the Main Board          | 101 |
| Replacing the USB board           | 103 |
| Replacing the Bluetooth Module    | 105 |
| Replacing the LCD Module          | 107 |
| Replacing the Power Board         | 109 |
| Replacing the Switch Board        | 110 |
| Replacing the Upper Cover         | 111 |
| Replacing the Keyboard            | 114 |
| Replacing the Wireless LAN Module | 115 |
| Replacing the DIMM Module         | 116 |
| Replacing the 2nd HDD Module      | 117 |
| Replacing the Hard Disk Drive     | 119 |
| Replacing the ODD Module          | 121 |
| Replacing the Base Door           | 123 |
| Replacing the Battery             | 124 |
| Replace the Dummy Card            | 124 |

## Troubleshooting

125

|                              |     |
|------------------------------|-----|
| Common Problems              | 125 |
| Power On Issue               | 126 |
| No Display Issue             | 127 |
| Random Loss of BIOS Settings | 128 |
| LCD Failure                  | 129 |
| Built-In Keyboard Failure    | 130 |
| TouchPad Failure             | 131 |



# Table of Contents

|   |            |
|---|------------|
| Internal Speaker Failure .....                  | 132        |
| Internal Microphone Failure .....               | 133        |
| HDD Not Operating Correctly .....               | 134        |
| USB Failure (Right up/down side) .....          | 135        |
| Other Failures .....                            | 135        |
| Intermittent Problems .....                     | 136        |
| Undetermined Problems .....                     | 136        |
| Post Code Reference Tables .....                | 137        |
| <b>Jumper and Connector Locations</b>           | <b>143</b> |
| Mainboard Top View .....                        | 143        |
| Mainboard Bottom View .....                     | 144        |
| Clearing Password Check and BIOS Recovery ..... | 145        |
| Mainboard CMOS Discharge .....                  | 145        |
| BIOS Recovery by Crisis Disk .....              | 146        |
| <b>FRU (Field Replaceable Unit) List</b>        | <b>147</b> |
| Exploded Diagrams .....                         | 147        |
| Main Assembly .....                             | 148        |
| LCD Assembly .....                              | 150        |
| FRU List .....                                  | 151        |
| Screw Table .....                               | 151        |
| <b>Model Definition and Configuration</b>       | <b>153</b> |
| <b>Test Compatible Components</b>               | <b>155</b> |
| <b>Online Support Information</b>               | <b>157</b> |

# ***Table of Contents***

# System Specifications

---

## Features

Below is a brief summary of the computer's many features:

### Operating System

- 

### Platform

- 

### System Memory

- Dual-channel DDR3 SDRAM support:
  - Up to 4 GB of DDR3 1066 MHz memory, upgradeable to 8 GB using two soDIMM modules (for 64-bit OS)

### Display

- 17" HD 1366 x 768 pixel resolution, high-brightness (200-nit) Acer CineCrystal™ LED-backlit TFT LCD, supporting simultaneous multi-window viewing via Acer GridVista™
- Mercury free, environment friendly
- 16:9 aspect ratio
- Super-slim design

### Graphics

- 

### Storage subsystem

- 

### Audio subsystem

- 

### Optical Media Drive

- 

### Communication

- Acer Video Conference1, featuring:
  - Acer Crystal Eye high-def webcam with 1280 x 1024 resolution

- 
- WLAN1, 10, 11:
    - Acer InviLink™ Nplify™ 802.11 b/g/n Wi-Fi CERTIFIED™.
    - Acer InviLink™ 802.11b/g Wi-Fi CERTIFIED™
  - WPAN1:Bluetooth® 2.1+EDR
  - WWAN1, 10, 12: UMTS/HSPA at 850/900/1900/2100 MHz and quad-band GSM/GPRS/EDGE(850/900/1800/1900 MHz), upgradeable to 7.2 Mb/s HSDPA and 5.7 Mb/s HSUPA, supporting receiver diversity and equalizing at 2100 MHz
  - LAN: Gigabit Ethernet, Wake-on-LAN ready

## Privacy control

- BIOS user, supervisor, HDD passwords,
- Kensington lock slot

## Dimensions and Weight

- 

## Power Adapter and Battery

- 

## Special Keys and Controls

- 103-/104-/107-key keyboard, with inverted "T" cursor layout
- 10 function keys, four cursor keys, two Windows® keys, hotkey controls, independent standard numeric keypad, international language support
- Media control keys (printed on keyboard): play/pause, stop, previous, next
- Multi-gesture touchpad, supporting two-finger scroll, pinch, rotate, flip

## I/O Ports

- Multi-in-1 card reader (SD™, MMC, MS, MS PRO, xD)
- Four USB 2.0 ports
- HDMI™ port with HDCP support
- External display (VGA) port
- Headphone/speaker/line-out jack with S/PDIF support
- Microphone-in jack
- Ethernet (RJ-45) port
- DC-in jack for AC adapterr

## Software

- 

## Optional Items

-

---

Warranty

•

Environment

---






# System Block Diagram




---

# Notebook Tour


This section provides an overview of the features and functions of the notebook.

## Top View



| # | Icon  | Item                    | Description   |
|---|---|-------------------------|---|
| 1 |   | Acer Crystal Eye webcam | Web camera for video communication. (only for certain models)   |
| 2 |  | Microphone              | Internal microphone for recording sound.  |
| 3 |   | Display screen          | Also called Liquid-Crystal Display (LCD), displays computer output (configuration may vary by model). |
| 4 |  | HDD indicator           | Indicates when the HDD is active.   |
|   |  | Num Lock indicator      | Lights up when the Num Lock is activated.   |
|   |  | Caps Lock indicator     | Lights up when the Caps Lock is activated.  |
| 5 |  | Power button/           | Turns the computer on and off.  |
| 6 |   | Keyboard                | For entering data into your computer  |
| 7 |   | Touchpad                | Touch-sensitive pointing device which functions like a computer mouse.                                |

| #  | Icon  | Item                            | Description   |
|----|---|---------------------------------|---|
| 8  |  | Power                           | Indicates the computer's power status.  |
|    |  | Battery                         | Indicates the computer's battery status.<br>1. Charging: The light shows amber when the light is charging.<br>2. Fully charged: the light shows blue when in AC mode. |
|    |  | Communication indicator         | Indicates the computer's wireless connectivity status.  |
| 9  |   | Click buttons (left, and right) | The left and right buttons function like the left and right mouse buttons.  |
| 10 |   | Palmrest                        | Comfortable support area for your hand when using the computer.   |
| 11 |   | Speakers                        | Left and right speakers deliver stereo audio output.  |
| 12 | <b>P</b>  | Programmable key                | User-programmable. (only for certain models)  |
|    |   |                                 |   |




## Closed Front View

| # | Icon  | Item                   | Description   |
|---|---|------------------------|---|
| 1 |  | Multi-in-1 card reader | Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD).<br>Note: Push to remove/install the card. Only one card can operate at any given time. |




## Left View

| # | Icon  | Item                 | Description   |
|---|---|----------------------|---|
| 1 |  | Kensington lock slot | Connects to a Kensington-compatible computer security lock. |
| 2 |   | Ventilation slots    | Enable the computer to stay cool, even after prolonged use. |
| 3 |  | Ethernet RJ-45) port | Connects to an Ethernet 10/100/1000-based network.          |
| 4 | HDMI  | HDMI port            | Supports high definition digital video connections.         |







| # | Icon  | Item  | Description  |
|---|---|---|--|
| 5 |  | USB 2.0 port  | Connects to USB 2.0 devices (e.g., USB mouse, USB camera).       |
| 6 |  | Microphone jack   | Accepts inputs from external microphones.                        |
|   |  | Headphones/<br>speaker/line-out<br>jack with S/PDIF<br>support. | Connects to audio line-out devices (e.g., speakers, headphones). |

## Right View

| # | Icon  | Item                             | Description  |
|---|---|----------------------------------|--|
| 1 |    | USB 2.0 port                     | Connects to USB 2.0 devices (e.g., USB mouse, USB camera).   |
| 2 |   | Optical drive                    | Internal optical drive; accepts CDs or DVDs.   |
| 3 |   | Optical disk<br>access indicator | Lights up when the optical drive is active.  |
| 4 |   | Emergency eject<br>hole          | Ejects the optical drive tray when the computer is turned off. Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off. |
| 5 |  | External display<br>(VGA) port   | Connects to a display device (e.g. external, LCD monitor, LCD projector).  |
| 6 |  | DC-in jack                       | Connects to an AC adapter.   |





---

## Base View

| # | Icon  | Item                              | Description  |
|---|---|-----------------------------------|--|
| 1 |   | Battery bay                       | Houses the computer's battery pack.<br>Note: The battery shown is for reference only. Your PC may have a different battery depending on the model purchased. |
| 2 |    | Battery lock                      | Locks the battery in position  |
| 3 |    | Hard disk bay                     | Houses the computer's hard disk (secured with screws)  |
| 4 |    | Memory compartment                | Houses the computer's main memory.   |
| 5 |   | Ventilation slots and cooling fan | Enable the computer to stay cool, even after prolonged use.<br>Note: Do not cover or obstruct the opening the fan.   |
| 6 |   | 2nd HDD bay                       | Houses the computer's second HDD   |
| 6 |  | Battery release latch             | Releases the battery for removal.  |

## Indicators

The computer has several easy-to-read status indicators. The battery indicator is visible even when the computer cover is closed.


| Icon  | Function     | Description   |
|---|--------------|---|
|  | Power        | Indicates the computer is on or off.                |
|   | Battery      | Indicates the computer's battery status.            |
|  | Wireless LAN | Indicates the status of Wireless LAN communication. |
|   | HDD          | Indicates when the hard disk drive is active.       |
|  | Num Lock     | Lights up when Num Lock is activated.               |
|  | Caps Lock    | Lights up when Caps Lock is activated.              |

**NOTE:** 1. **Charging:** The battery light shows amber when the battery is charging. 2. **Fully charged:** The light shows green when in AC mode.

---

# TouchPad Basics

The following items show you how to use the TouchPad:




- Move your finger across the TouchPad (1) to move the cursor.
- Press the left (2) and right (3) buttons located beneath the TouchPad to perform selection and execution functions. These two buttons are the equivalent of the left and right buttons on a mouse. Tapping on the TouchPad is the same as clicking the left button.

| Function            | Left Button (2)   | Right Button (3) | Main TouchPad (1)  |
|---------------------|---|------------------|--|
| Execute             | Quickly click twice.  |                  | Tap twice (at the same speed as double-clicking a mouse button).   |
| Select              | Click once.   |                  | Tap once.  |
| Drag                | Click and hold, then use finger on the TouchPad to drag the cursor. |                  | Tap twice (at the same speed as double-clicking a mouse button); rest your finger on the TouchPad on the second tap and drag the cursor. |
| Access context menu |   | Click once.      |  |

**NOTE:** When using the TouchPad, keep it - and your fingers - dry and clean. The TouchPad is sensitive to finger movement; hence, the lighter the touch, the better the response. Tapping too hard will not increase the TouchPad's responsiveness.

# Using the Keyboard

Your computer has a close-to-full-sized keyboard and an embedded numeric keypad, separate cursor, lock, function and special keys.



## Lock Keys and embedded numeric keypad

The keyboard has three lock keys which you can toggle on and off.














| Lock key                 | Description  |
|--------------------------|--|
| Caps Lock                | When Caps Lock is on, all alphabetic characters typed are in uppercase.  |
| Num Lock                 | When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad. |
| Scroll Lock <Fn> + <F12> | When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.  |

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

| Desired access                         | Num Lock on  | Num Lock off                               |
|--|--|--|
| Number keys on embedded keypad         | Type numbers in a normal manner.                   |  |
| Cursor-control keys on embedded keypad | Hold <Shift> while using cursor-control keys.      | Hold <Fn> while using cursor-control keys. |
| Main keyboard keys                     | Hold <Fn> while typing letters on embedded keypad. | Type the letters in a normal manner.       |


# Windows Keys

The keyboard has two keys that perform Windows-specific functions.

| Key   | Description  |
|---|--|
|  Windows key     | <p>Pressed alone, this key has the same effect as clicking on the Windows Start button; it launches the Start menu. It can also be used with other keys to provide a variety of functions:</p> <ul style="list-style-type: none"><li>&lt;  &gt;: Open or close the Start menu</li><li>&lt;  &gt; + &lt;D&gt;: Display the desktop</li><li>&lt;  &gt; + &lt;E&gt;: Open Windows Explore</li><li>&lt;  &gt; + &lt;F&gt;: Search for a file or folder</li><li>&lt;  &gt; + &lt;L&gt;: Lock your computer (if you are connected to a network domain), or switch users (if you're not connected to a network domain)</li><li>&lt;  &gt; + &lt;M&gt;: Minimizes all windows</li><li>&lt;  &gt; + &lt;R&gt;: Open the Run dialog box</li><li>&lt;  &gt; + &lt;U&gt;: Open Ease of Access Center</li><li>&lt;  &gt; + &lt;BREAK&gt;: Display the System Properties dialog box</li><li>&lt;  &gt; + &lt;TAB&gt;: Cycle through programs on the taskbar</li><li>&lt;CTRL&gt; + &lt;  &gt; + &lt;F&gt;: Search for computers (if you are on a network)</li></ul> <p><b>Note:</b> Depending on your edition of Windows 7, some shortcuts may not function as described.</p> |
|  Application key | This key has the same effect as clicking the right mouse button; it opens the application's context menu.  |

# Hot Keys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness and volume output.



To activate hotkeys, press and hold the <Fn> key before pressing the other key in the hotkey combination.

| Hotkey         | Icon | Function                      | Description   |
|----------------|------|-------------------------------|---|
| <Fn> + <F3>    |      | Wireless communication switch | Enables/disables the Wireless function.   |
| <Fn> + <F4>    |      | Sleep                         | Puts the computer in Sleep mode.  |
| <Fn> + <F5>    |      | Display toggle                | Switches display output between the display screen, external monitor (if connected) and both. |
| <Fn> + <F6>    |      | Screen blank                  | Turns the display screen backlight off to save power. Press any key to return.                |
| <Fn> + <F7>    |      | Touchpad toggle               | Turns the touchpad on and off.  |
| <Fn> + <F8>    |      | Speaker toggle                | Turns the speakers on and off.  |
| <Fn> + <D>     |      | Brightness up                 | Increases the screen brightness.  |
| <Fn> + <Q>     |      | Brightness down               | Decreases the screen brightness.  |
| <Fn> + <Δ>     |      | Volume up                     | Increases the sound volume.   |
| <Fn> + <∇>     |      | Volume down                   | Decreases the sound volume.   |
| <Fn> + <Home>  |      | Play/Pause                    | Plays or pauses media files   |
| <Fn> + <Pg Up> |      | Stop                          | Stops media file  |
| <Fn> + <Pg Dn> |      | Previous                      | Plays the previous media file in the play sequence  |
| <Fn> + <End>   |      | Next                          | Plays the next media file in the play sequence  |

---

## Special Keys

On models that support the Euro symbol and the US dollar sign, the symbols can be located at the upper-center and/or bottom-right of your keyboard.

### The Euro symbol

1. Open a text editor or word processor.
2. Hold <Alt Gr> and then press the <5> key at the upper-center of the keyboard.

**NOTE:** Some fonts and software do not support the Euro symbol. See [www.microsoft.com/typography/faq/faq12.htm](http://www.microsoft.com/typography/faq/faq12.htm) for more information.

### The US dollar sign

1. Open a text editor or word processor.
2. Hold <Shift> and then press the <4> key at the upper-center of the keyboard.

**NOTE:** This function varies according to the language settings.

# Hardware Specifications and Configurations

## Processor

| Item           | Specification |
|----------------|---------------|
| CPU            | •             |
| Type           | •             |
| CPU Package    |               |
| Power          |               |
| On-die Cache   | •             |
| Front Side Bus |               |

## Processor Specifications

| Item | CPU Speed | Cores | Bus Speed | Cache Size | Package | Core Voltage | Acer P/N |
|------|-----------|-------|-----------|------------|---------|--------------|----------|
|      |           |       |           |            |         |              |          |
|      |           |       |           |            |         |              |          |
|      |           |       |           |            |         |              |          |
|      |           |       |           |            |         |              |          |

## CPU Fan True Value Table (UMA)

| CPU Temperature (Celcius) | Fan Speed (RPM) | SPL Spec (dBA) |
|---------------------------|-----------------|----------------|
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |

Throttling 50%: On= 100°C; OFF=85°C

OS shut down at 105°C; H/W shut down at 110°C

## CPU Fan True Value Table (Discrete)

| CPU Temperature (Celcius) | Fan Speed (RPM) | SPL Spec (dBA) |
|---------------------------|-----------------|----------------|
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |
|                           |                 |                |

Throttling 50%: On= 100°C; OFF=85°C

OS shut down at 105°C; H/W shut down at 110°C

## Core Logic Specifications

| Item     | Specification |
|----------|---------------|
| Chipset  |               |
| Package  |               |
| Features | •             |



### System Memory

| Item                            | Specification            |
|---------------------------------|--------------------------|
| Memory size                     | 0MB (No on-board Memory) |
| DIMM socket number              | 2 sockets                |
| Supports memory size per socket | 4GB                      |
| Supports maximum memory size    | 8GB                      |
| Supports DIMM type              | DDR3 64 bit              |
| Supports DIMM Speed             | 1066/1333 MHz            |

### Video Specifications

| Item     | Specification |
|----------|---------------|
| Chipset  |               |
| Type     |               |
| Package  | •             |
| Features | •             |

### Hard Disk Drive Interface

| Item                       | Specification      |                    |                    |                         |
|----------------------------|--------------------|--------------------|--------------------|-------------------------|
| Vendor & Model Name        | Seagate            | HGST               | Toshiba            | Western Digital         |
| Capacity (GB)              | 160, 250, 320, 500 | 160, 250, 320, 500 | 160, 250, 320, 500 | 160, 250, 320, 500, 640 |
| Bytes per sector           | 512                |                    |                    |                         |
| Data heads                 | 2-4                |                    |                    |                         |
| Drive Format               |                    |                    |                    |                         |
| Disks                      | 1-2                |                    |                    |                         |
| Spindle speed (RPM)        | 5400               |                    |                    |                         |
| Performance Specifications |                    |                    |                    |                         |
| Buffer size                | 8 MB               |                    |                    |                         |
| Interface                  | SATA               |                    |                    |                         |
| DC Power Requirements      |                    |                    |                    |                         |
| Voltage tolerance          | 5V ±5%             | 5V ±5%             | 5V ±5%             | 5V ±5%                  |

### BIOS

| Item          | Specification |
|---------------|---------------|
| BIOS vendor   | Insyde BIOS   |
| BIOS version  | 3.5           |
| BIOS ROM type | Flash         |

| Item     | Specification  |
|----------|--|
| Features | <ul style="list-style-type: none"> <li>Flash ROM 4MB</li> <li>Support ISIPP</li> <li>Support Acer UI</li> <li>Support multi-boot</li> <li>Suspend to RAM (S3)/Disk (S4)</li> <li>Various hot-keys for system control</li> <li>Support SMBIOS 2.3, PCI2.2.</li> <li>Refer to Acer BIOS specification.</li> <li>DMI utility for BIOS serial number configurable/asset tag</li> <li>Support PXE</li> <li>Support Y2K solution</li> <li>Support WinFlash</li> <li>Wake on LAN from S3</li> <li>Wake on LAN form S4 in AC mode</li> <li>System information</li> </ul> |

### LCD 17.3"

| Item   | Specification     |             |             |             |
|--|-------------------|-------------|-------------|-------------|
| Vendor/model name  | AUO/              | ChiMei      | LG          | Samsung     |
| Screen Diagonal (mm)   | 17.3 inches       |             |             |             |
| Display resolution (pixels)  | 1600x3(RGB) x 900 |             |             |             |
| Pixel Pitch  | 0.2388X0.2388     |             |             |             |
| Display Mode   | Normally White    |             |             |             |
| Typical White Luminance (cd/m <sup>2</sup> )<br>(also called Brightness) | 220 typical       |             |             |             |
| Contrast Ratio   | 500 typical       | 500         | 600         | 600         |
| Response Time (Optical Rise<br>Time/Fall Time) msec                      | 8/16              | 2/8         | 8/16        | 8           |
| Luminance Uniformity   | 1.25 max          |             |             |             |
| Electrical Interface   | LVDS              |             |             |             |
| Support Color  | 262K              |             |             |             |
| Viewing Angle (up/down/right/<br>left)                                   | 15/35/45/45       | 20/45/45/45 | 10/30/40/40 | 15/30/40/40 |
| Temperature Range (°C)   |                   |             |             |             |
| Operating  | 0 to +50          |             |             |             |
| Storage (shipping)   | -20 to +60        |             |             |             |

### Bluetooth

| Item                    | Specification                                    |  |
|-------------------------|--|--|
| Bluetooth<br>Controller | Foxconn BCM2046 BT2.1+EDR<br>Module (T60H928.33) | Foxconn AR3011 BT Module<br>(T77H056.00) |

| Item     | Specification  |   |
|----------|--|---|
| Features | <ul style="list-style-type: none"> <li>Fully Qualified Bluetooth v2.1 with Class 2 specification RF output power.</li> <li>Enhanced Data Rate (EDR) compliant.</li> <li>Full Piconet and Scatternet operation.</li> <li>Integrated PIFA Antenna with better RF performance.</li> <li>USB 2.0 compliant interface.</li> <li>F/W upgradable via Flash downloads.</li> <li>Very low power consumption.</li> <li>Support Coexistence with Intel WCS (Wireless Coexistence System) &amp; AFH (Adaptive Frequency Hopping).</li> </ul> | <ul style="list-style-type: none"> <li>Single-chip Bluetooth v2.1 + EDR solution</li> <li>USB 2.0 full-speed device interface with support for Device Firmware Upgrade(DFU)</li> <li>SPI interface supports external serial flash devices</li> <li>Two on-chip 1.2V linear voltage regulators</li> <li>Integrated 32-bit CPU with 32KB data RAM and 256KB program RAM</li> <li>On-board PLL</li> <li>On-chip low power oscillator(LPO)</li> <li>WLAN coexistence interface</li> <li>Standard USB HCI interface</li> </ul> |

#### Audio Codec and Amplifier

| Item             | Specification |
|------------------|---------------|
| Audio Controller |               |
| Package          |               |
| Features         | •             |

#### LAN Interface

| Item        | Specification |
|-------------|---------------|
| LAN Chipset |               |
| Package     |               |
| Features    | •             |

#### Keyboard

| Item   | Specification |
|--|---------------|
| Type   |               |
| Total number of keypads                          |               |
| Windows logo key                                 |               |
| Internal & external keyboard work simultaneously |               |
| Features   | •             |

#### Media Card Reader

| Item     | Specification |
|----------|---------------|
| Chipset  |               |
| Package  |               |
| Features | •             |

#### Camera 1.3M

| Item             | Specifications        |                 |                                     |
|------------------|-----------------------|-----------------|-------------------------------------|
| Vendor and model | SUYIN HF1315-S32B-OV0 | Chicony CNF9157 | Liteon 09P2BF127 / Liteon 09P2SF119 |

| Item                      | Specifications                   |  |                             |
|---------------------------|----------------------------------|--|-----------------------------|
| Type                      | CMOS image sensor with SXGA      | CMOS image sensor with SXGA            | CMOS image sensor with SXGA |
| Interface                 | USB Port 2.0                     | USB Port 2.0                           | USB Port 2.0                |
| Focusing distance         | 70cm                             | 70 cm                                  | 60 cm                       |
| Dimensions (L x W x H mm) | 65 x 8.0 x 3.74 mm               | 65.0±0.3 X 8.0±0.1 X 3.69+0.11/-0.2 mm | 65.0 x 8.0 x 3.53 ± 0.2mm   |
| Sensor type               | OV9665                           | TBC                                    | OV9665                      |
| Pixel resolution          | 1280x1024                        | 1280x1024                              | 1280x1024                   |
| Pixel size                | 2 µm x 2 µm                      | TBC                                    | 2 µm x 2 µm                 |
| Image size                | 3.89mm(H) X 2.43mm(V)Part number | TBC                                    | TBC                         |

#### Wireless LAN

|                              | Specification    |                |                      |
|------------------------------|------------------|----------------|----------------------|
| Type                         | Realtek RTL819SE | Atheros AR5B93 | Intel WiFi Link 1000 |
| Wireless Standards Supported | b, g, n          | b, g, n        | b, g, Draft-N        |

#### Battery

| Item                   | Specification |
|------------------------|---------------|
|                        | 6 Cell        |
| Vendor & model name    |               |
| Battery Type           |               |
| Pack capacity          |               |
| Number of battery cell |               |
| Package configuration  |               |

# System Utilities

---

## BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your computer's BIOS (Basic Input/Output System).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run Setup. Please also refer to Chapter 4 Troubleshooting when problem arises.

To activate the BIOS Utility, press **F2** during POST (when **Press <F2> to enter Setup** message is prompted on the bottom of screen).

Press **F2** to enter setup. The default parameter of F12 Boot Menu is set to "disabled". If you want to change boot device without entering BIOS Setup Utility, please set the parameter to "enabled".

Press **<F12>** during POST to enter multi-boot menu. In this menu, user can change boot device without entering BIOS SETUP Utility.

## Navigating the BIOS Utility

There are five menu options: Information, Main, Security, Boot, and Exit.


Follow these instructions:

- To choose a menu, use the left and right arrow keys.
- To choose an item, use the up and down arrow keys.
- To change the value of a parameter, press **F5** or **F6**.
- Press **Esc** while you are in any of the menu options to go to the Exit menu.
- In any menu, you can load default settings by pressing **F9**. You can also press **F10** to save any changes made and exit the BIOS Setup Utility.

**NOTE:** You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen. Help for parameters are found in the Item Specific Help part of the screen. Read this carefully when making changes to parameter values. **Please note that system information is subject to different models.**

# Information

The Information screen displays a summary of your computer hardware information.




**NOTE:** The system information is subject to different models.

| Parameter           | Description  |
|---------------------|--|
| CPU Type            | This field shows the CPU type and speed of the system.   |
| CPU Speed           | This field shows the speed of the CPU.   |
| IDE0 Model Name     | This field shows the model name of HDD installed on primary IDE master.  |
| IDE0 Serial Number  | This field displays the serial number of HDD installed on primary IDE master.  |
| IDE1 Serial Number  | This field shows the model name of the device nstalled on secondary IDE master.  |
| IDE1 Serial Number  | This field displays the serial number of the device installed on secondary IDE master.   |
| ATAPI Model Name    | This field displays the model name of the installed ODD drive.   |
| System BIOS Version | Displays system BIOS version.  |
| VGA BIOS Version    | This field displays the VGA firmware version of the system.  |
| Serial Number       | This field displays the serial number of this unit.  |
| Asset Tag Number    | This field displays the asset tag number of the system.  |
| Product Name        | This field shows product name of the system.   |
| Manufacturer Name   | This field displays the manufacturer of this system.   |
| UUID Number         | Universally Unique Identifier (UUID) is an identifier standard used in software construction, standardized by the Open Software Foundation (OSF) as part of the Distributed Computing Environment (DCE). |

# Main

The Main screen allows the user to set the system time and date as well as enable and disable boot option and recovery.




**NOTE:** The screen above is for your reference only. Actual values may differ.

The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

| Parameter     | Description   | Format/Option                         |
|---------------|---|---------------------------------------|
| System Time   | Sets the system time. The hours are displayed with 24-hour format.  | Format: HH:MM:SS (hour:minute:second) |
| System Date   | Sets the system date.   | Format MM/DD/YYYY (month/day/year)    |
| Total Memory  | This field reports the memory size of the system.   | N/A                                   |
| Video Memory  | Shows the video memory size. VGA Memory size=32 MB  | N/A                                   |
| Graphic Mode  | Sets discrete VGA only for systems with XP or Linux OS.   | Option: <b>Switchable</b> or Discrete |
| Quiet Boot    | This will hide POST messages while booting.   | Option: <b>Enabled</b> or Disabled    |
| Network Boot  | Enables, disables the system boot from LAN (remote server).   | Option: <b>Enabled</b> or Disabled    |
| F12 Boot Menu | Enables, disables Boot Menu during POST.  | Option: <b>Disabled</b> or Enabled    |
| D2D Recovery  | Enables, disables D2D Recovery function. The function allows the user to create a hidden partition on hard disc drive to store the operation system and restore the system to factory defaults. | Option: <b>Enabled</b> or Disabled    |
| SATA Mode     | Control the mode in which the SATA controller should operate.   | Option: <b>AHCI mode</b> or IDE mode  |

# Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.



The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

| Parameter               | Description  | Option                     |
|-------------------------|--|----------------------------|
| Supervisor Password Is  | Shows the setting of the Supervisor password   | <b>Clear</b> or Set        |
| User Password Is        | Shows the setting of the user password.  | <b>Clear</b> or Set        |
| HDD Password Is         | Shows the setting of the HDD password  | <b>Clear</b> or Set        |
| Set Supervisor Password | Press Enter to set the supervisor password. When set, this password protects the BIOS Setup Utility from unauthorized access. The user can not either enter the Setup menu nor change the value of parameters.                         |                            |
| Set User Password       | Press Enter to set the user password. When user password is set, this password protects the BIOS Setup Utility from unauthorized access. The user can enter Setup menu only and does not have right to change the value of parameters. |                            |
| Set HDD Password        | Press Enter to set the HDD password. When set this protects the HDD from unauthorized access.  |                            |
| Password on Boot        | Defines whether a password is required or not while the events defined in this group happened. The sub-options all require the Supervisor password for changes and should be grayed out if the user password was used to enter setup.  | <b>Disabled</b> or Enabled |

**NOTE:** When you are prompted to enter a password, you have three tries before the system halts. Don't forget the password. If you forget the password, you may have to reset the computer.




---

## Setting a Password

Follow these steps as you set the user or the supervisor password:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Supervisor Password box appears:



| Set Supervisor Password |                |
|-------------------------|----------------|
| Enter New Password      | [ ██████████ ] |
| Confirm New Password    | [            ] |

2. Type a password in the “Enter New Password” field. The password length can not exceeds 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive). Retype the password in the “Confirm New Password” field.

**IMPORTANT:** Be very careful when typing your password because the characters do not appear on the screen.

3. Press **Enter**. After setting the password, the computer sets the User Password parameter to “Set”.
4. If desired, you can opt to enable the Password on boot parameter.
5. When you are done, press F10 to save the changes and exit the BIOS Setup Utility.

## Removing a Password

Follow these steps:

1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears:



| Set Supervisor Password |                |
|-------------------------|----------------|
| Enter Current Password  | [ ██████████ ] |
| Enter New Password      | [            ] |
| Confirm New Password    | [            ] |

2. Type the current password in the Enter Current Password field and press **Enter**.
3. Press **Enter** twice **without** typing anything in the Enter New Password and Confirm New Password fields. The computer then sets the Supervisor Password parameter to “Clear”.
4. When you have changed the settings, press **F10** to save the changes and exit the BIOS Setup Utility.

---

## Changing a Password


1. Use the ↑ and ↓ keys to highlight the Set Supervisor Password parameter and press the **Enter** key. The Set Password box appears.



The screenshot shows a blue BIOS screen titled "Set Supervisor Password". It contains three input fields: "Enter Current Password", "Enter New Password", and "Confirm New Password". The first field is filled with blacked-out characters, while the other two are empty.

2. Type the current password in the Enter Current Password field and press **Enter**.
3. Type a password in the Enter New Password field. Retype the password in the Confirm New Password field.
4. Press **Enter**. After setting the password, the computer sets the User Password parameter to "Set".
5. If desired, you can enable the Password on boot parameter.
6. When you are done, press **F10** to save the changes and exit the BIOS Setup Utility.

If the verification is OK, the screen will display as following.



The screenshot shows a white BIOS screen titled "Setup Notice". The text "Changes have been saved." is displayed in the center. At the bottom, there is a black button labeled "Continue".

The password setting is complete after the user presses **Enter**.

If the current password entered does not match the actual current password, the screen will show you the Setup Warning.



The screenshot shows a white BIOS screen titled "Setup Warning" in red text. Below the title, the text "Invalid Password." is displayed in red. At the bottom, there is a black button labeled "Continue".

If the new password and confirm new password strings do not match, the screen displays the following message.



The screenshot shows a white BIOS screen titled "Setup Warning" in red text. Below the title, the text "Passwords do not match. Re-enter password." is displayed in red. At the bottom, there is a black button labeled "Continue".


# Boot

This menu allows the user to decide the order of boot devices to load the operating system. Bootable devices includes the USB diskette drives, the onboard hard disk drive and the DVD drive in the module bay.

| Phoenix SecureCore (tm) Setup Utility   |                |                        |   |      |
|---|----------------|------------------------|---|------|
| Information   | Main           | Security               | Boot  | Exit |
| Boot priority order:<br>1: IDE 0: Hitachi HTS545016B9A300-(S)<br>2: IDE 5: ST9160314AS-(S6)<br>3: CD/DVD: Optiarc DVD RW AD-758H-(S)<br>4: PCI LAN: Atheros Boot Agent<br>5: USB HDD:<br>6: USB CDROM:<br>7: USB FFD:<br>8: USB KEY:<br>Excluded from boot order: |                |                        | Item Specific Help<br><br>Use <↑> or <↓> to select a device, then press <F6> to move it up the list, or <F5> to move it down the list.<br>Press <Esc> to escape the menu. |      |
| F1 Help   | ↑↓ Select Item | F5/F6 Change Values    | F9 Setup Default  |      |
| ESC Exit  | ← Select Menu  | Enter Select ► SubMenu | F10 Save and Exit   |      |

# Exit

The Exit screen allows you to save or discard any changes you made and quit the BIOS Utility.



The table below describes the parameters in this screen.

| Parameter               | Description   |
|-------------------------|---|
| Exit Saving Changes     | Exit System Setup and save your changes to CMOS.    |
| Exit Discarding Changes | Exit utility without saving setup data to CMOS.     |
| Load Setup Default      | Load default values for all SETUP item.             |
| Discard Changes         | Load previous values from CMOS for all SETUP items. |
| Save Changes            | Save Setup Data to CMOS.                            |

# BIOS Flash Utility


The BIOS flash memory update is required for the following conditions:

- New versions of system programs
- New features or options
- Restore a BIOS when it becomes corrupted.

## DOS Flash Utility


Perform the following steps to use the DOS Flash Utility:

1. Press F2 during boot to enter the Setup Menu.
2. Select **Boot Menu** to modify the boot priority order, for example, if using USB HDD to Update BIOS, move USB HDD to position 1.



3. Execute the **FLASH.BAT** batch file to update BIOS. Or enter C:\ **Flash it bios ver.f/d/c**

The flash process begins as shown.



4. In flash BIOS, the message **Please do not remove AC Power Source** displays.

**NOTE:** If the AC power is not connected, the following message displays.



Plug in the AC power to continue.

5. Flash is complete when the message Flash programming complete displays.

## WinFlash Utility

Perform the following steps to use the WinFlash Utility:

1. Double click the WinFlash executable.
2. Click **OK** to begin the update. A progress screen displays.
3. When the process is complete, close all programs and applications and reboot the system.


---

# Remove HDD/BIOS Password Utilities

This section provide you with removing HDD/BIOS method:


## Remove HDD Password:

When the user keys in the wrong password three times, the system reports the following error code to user.



To unlock the HDD password, perform the following steps:

1. Press **Enter** to display the Select Item screen.



2. Select **Enter Unlock Password** and press **Enter**.

An Unlock Password displays.




3. Make a note of the key, **76943488** in the example.
4. Boot up the system to a removable bootable drive containing DOS and the UnlockHD.EXE program and open a DOS prompt. For instructions on changing boot priority see "Boot" on page 25.
5. From the DOS prompt, enter the **UnlockHD.EXE** command and input the key to create an unlock code. Make a note of the result, for example **46548274**.
6. Reboot to the hard disk and wait for the error code to reappear.
7. Press **Enter** to display the Select Item screen.
8. Select **Enter Unlock Password** and press **Enter**.
9. Enter the unlock code generated by UnlockHD.EXE.
10. Save and exit the BIOS to complete the process.

---

## Removing BIOS Passwords:

If you key in the wrong Supervisor Password three times, System Disabled displays on the screen. See the image below.



To reset the BIOS password, run clnpwd.exe as follows:

1. From a DOS prompt, Execute **clnpwd.exe**

```
d:\Clnpwd>clnpwd
ACER Clean Password Utility V1.00
Press 1 or 2 to clean any password shown as below
    1.User Password
    2.Supervisor Password

Clean User Password Successfully!
```

2. Press 1 or 2 to clean the desired password shown on the screen.

The onscreen message determines whether the function is successful or not.



---

# Miscellaneous Utilities

## Using Boot Sequence Selector

Boot Sequence Selector allows the boot order to be changes without accessing the BIOS. To use Boot Sequence Selector, perform the following steps:

1. Enter into DOS.
2. Execute BS.exe to display the usage screen.

```
d:\B00TSEQ>bs
*** Boot Sequence Selector Version 0.03 ***
Create by Rockwell Chuang 10/01/2005.
Usage:
      BS [ 1 | 2 | 3 | 4 ]
BS 1 : [ Floppy ] => [ HardDisk ] => [ CD-ROM ] => [ LAN   ]
BS 2 : [ HardDisk ] => [ CD-ROM ] => [ LAN   ] => [ Floppy ]
BS 3 : [ CD-ROM ] => [ HardDisk ] => [ LAN   ] => [ Floppy ]
BS 4 : [ LAN   ] => [ Floppy ] => [ HardDisk ] => [ CD-ROM ]
d:\B00TSEQ>
```

3. Select the desired boot sequence by entering the corresponding sequence, for example, enter BS2 to change the boot sequence to HDD|CD ROM|LAN|Floppy.

## Using DMITools

The DMI (Desktop Management Interface) Tool copies BIOS information to eeprom to be used in the DMI pool for hardware management.

When the BIOS displays **Verifying DMI pool data** it is checking the table correlates with the hardware before sending to the operating system (Windows, etc.).

To update the DMI Pool, perform the following steps:

1. Enter into DOS.
2. Execute **qdmtools.exe**. The following messages show dmitools usage:

```
*** Compal DMI String R/W Utility Ver1.40 for 2006/03/14 ***

Usage:

DMITOOLS [/R | /WP | /WS | /WU] [ STRING ]

[/R]   : Read DMI Information from Memory
[/WM]  : Write Manufacturer Name to EEPROM. (Max.= 16 characters)
[/WP]  : Write Product Name to EEPROM.     (Max.= 16 characters)
[/WS]  : Write Serial Number to EEPROM     (Max.= 22 characters)
[/WU]  : Write UUID to EEPROM.             (Ignore String )
[/WA]  : Write Asset Tag to EEPROM.        (Max.= 32 characters)
```


3. Enter the required key number of the feature required to be modified. See the following table.

| Key No. | Function Description                          |
|---------|---|
| 1       | Enter <b>1</b> to modify the Asset Tag        |
| 2       | Enter <b>2</b> to modify the Product Name     |
| 3       | Enter <b>3</b> to modify the Serial Number    |
| 4       | Enter <b>4</b> to modify the 1394 GUID Number |
| 0       | Enter <b>0</b> to exit the program            |

## Using the LAN MAC Utility

Perform the following steps to write MAC information to eeprom:

1. Use a text editor, for example Notepad, to edit the MAC.CFG file as shown:



```
MAC.CFG - Notepad
File Edit Format View Help
Title= MAC Address byte
WriteData='001122334455'
StartAddr=7A
WriteLeng=6
KeepByte=0
```

- WriteData= '001122334455' <----- MAC value
  - StartAddr=7A <----- MAC address
  - WriteLeng=6 <----- MAC value length
  - KeepByte=0 <----- can be any value
2. Boot into DOS.
3. Execute **MAC.BAT** to write MAC information to eeprom.

# Machine Disassembly and Replacement

---

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

## Disassembly Requirements

To disassemble the computer, you need the following tools:

- Wrist grounding strap and conductive mat for preventing electrostatic discharge
- Flat screwdriver
- Philips screwdriver
- Plastic flat screwdriver
- Plastic tweezers

**NOTE:** The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

## Related Information

The product previews seen in the disassembly procedures may not represent the final product color or configuration.

**IMPORTANT:** Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

## Replacement Requirements

**NOTE:** Cabling and components require adhesive to be applied during the replacement and reassembly process.

**NOTE:** During manufacture a cyanoacrylate glue is used provided by Holdtite Adhesives LTD. This is not a specified requirement. The reassembler is free to select an alternative appropriate adhesive.

---

## Pre-disassembly Instructions

Before proceeding with the disassembly procedure, make sure that you do the following:

1. Turn off the power to the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.



3. Place the system on a flat, stable surface.

---

# Disassembly Process

The disassembly process is divided into the following sections:

- External components disassembly
- Main unit disassembly
- LCD module disassembly

The flowcharts provided in the succeeding disassembly sections illustrate the entire disassembly sequence. Observe the order of the sequence to avoid damage to any of the hardware components. For example, if you want to remove the Mainboard, you must first remove the Keyboard, and LCD Module then disassemble the inside assembly frame in that order.

## Main Screw List

| Screw         | Quantity | Acer Part Number |
|---------------|----------|------------------|
| M2.0*3L(BK)   | 14       |                  |
| M2.5*5L(NI)   | 8        |                  |
| M2.5*4L(BNI)  | 12       |                  |
| M3.0*3.5L(NI) | 6        |                  |
| M2.5*5L(BNI)  | 7        |                  |
| M2.0*5L       | 4        |                  |
| M2.5*6L(BNI)  | 38       |                  |
| M2.5*2L(NI)   | 4        |                  |


# External Module Disassembly Process

**NOTE:** The product previews seen in the disassembly procedures may not represent the final product color or configuration.

### Screw List

| Step                      | Screw         | Quantity | Part No. |
|---------------------------|---------------|----------|----------|
| Base Cover Disassembly    | M2.5*5L(BNI)  | 6        |          |
| 2nd HDD Cover Disassembly | M2.5*5L(BNI)  | 1        |          |
| WLAN Module Disassembly   | M2.0*3L(BK)   | 1        |          |
| HDD Disassembly           | M3.0*3.5L(NI) | 2        |          |
| 2nd HDD Disassembly       | M3.0*3.5L(NI) | 4        |          |
| ODD Module Disassembly    | M2.0*3L(BK)   | 1        |          |

## External Modules Disassembly Flowchart




---


## Removing the Battery Pack

1. Turn the computer over.
2. Slide the battery lock/unlock latch to the unlock position.



3. Slide and hold the battery release latch to the release position (1), then slide out the battery pack from the main unit (2).



 **NOTE:** The battery has been highlighted with a yellow oval as shown in the above image. Please detach the battery and follow local regulations for disposal.

---

## Removing the Dummy Card

1. Press the dummy card in to allow it to spring out.




2. Pull the dummy card out.







## Removing the Base Door

1. See “Removing the Battery Pack” on page 37.
2. Remove the six (6) screws.



| Step                  | Screw        | Quantity | Screw Type   |
|-----------------------|--------------|----------|--|
| Base Door Disassembly | M2.5*5L(BNI) | 6        |  |


3. Lift the base door up at the finger indentation location provided in the bottom cover.




---

## Removing the Hard Disk Drive Module


1. See “Removing the Battery Pack” on page 37.
2. See “Removing the Base Door” on page 39.
3. Grasp the pull tab on the top of the HDD.



4. Pull the tab horizontally to slide the HDD out of the connector dock.




5. Lift the HDD out of the lower cover.




6. Remove the two (2) screws of the HDD bracket.



| Step                    | Screw         | Quantity | Screw Type  |
|-------------------------|---------------|----------|---|
| HDD Bracket Disassembly | M3.0*3.5L(NI) | 2        |  |


7. Lift the bracket away from the HDD.




---

## Removing the DIMM Module

1. See “Removing the Battery Pack” on page 37.
2. See “Removing the Base Door” on page 39.
3. Push the memory module clips outwards.



4. Pull the memory module out.




# Removing the WLAN Module


1. See “Removing the Battery Pack” on page 37.
2. See “Removing the Base Door” on page 39.
3. Detach the two (2) cables from the Wireless LAN module.

**IMPORTANT:** Take note of the position of the Main (black) and Auxiliary (white) connectors.




4. Remove the one (1) screw. Ensure the cables are well clear of the module.



| Step                    | Screw       | Quantity | Screw Type   |
|-------------------------|-------------|----------|--|
| WLAN Module Disassembly | M2.0*3L(BK) | 1        |  |

- 
5. Pull the WLAN module out and away.




---


## Removing the 2nd HDD Module

1. See "Removing the Battery Pack" on page 37.
2. Remove the one (1) screw from the 2nd HDD module door.




| Step                       | Screw        | Quantity | Screw Type   |
|----------------------------|--------------|----------|--|
| 2nd HDD Module Disassembly | M2.5*5L(BNI) | 1        |  |


3. Remove the HDD module door from the lower cover.



4. Grasp the pull tab on the top of the HDD.




5. Lift the HDD out of the lower cover.




6. Remove the four (4) screws from the HDD bracket.



| Step                    | Screw         | Quantity | Screw Type  |
|-------------------------|---------------|----------|---|
| HDD Bracket Disassembly | M3.0*3.5L(NI) | 4        |  |




- 
7. Lift the bracket away from the HDD.




# Removing the ODD Module

1. See "Removing the Battery Pack" on page 37.
2. See "Removing the Base Door" on page 39.
3. Pry the ODD from the chassis and pull the ODD completely out of the bay.



4. Remove the two (2) screws from the ODD bracket.



| Step                   | Screw       | Quantity | Screw Type  |
|------------------------|-------------|----------|---|
| ODD Module Disassembly | M2.0*3L(BK) | 2        |  |

- 
5. Remove the ODD bracket.



6. Pry the ODD bezel off of the ODD module.



# Main Unit Disassembly Process

**IMPORTANT:** Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

**NOTE:** The product previews seen in the disassembly procedures may not represent the final product color or configuration.

## Main Unit Disassembly Flowchart



### Screw List

| Step                     | Screw        | Quantity | Part No. |
|--------------------------|--------------|----------|----------|
| Upper Cover Disassembly  | TBD          |          |          |
| Lower Cover Disassembly  | TBD          |          |          |
| Switch Board Disassembly | M2.5*2L(NI)  | 2        |          |
| Power Module Disassembly | M2.0*3L(BK)  | 3        |          |
| USB board Disassembly    | M2.5*6L(BNI) | 1        |          |


---



| Step                         | Screw        | Quantity | Part No. |
|------------------------------|--------------|----------|----------|
| Bluetooth Module Disassembly | TBD          |          |          |
| LAN Board Disassembly        | TBD          |          |          |
| PCH Heatsink Disassembly     | TBD          |          |          |
| LCD Module Disassembly       | M2.5*6L(BNI) | 4        |          |

# Removing the Keyboard


**IMPORTANT:** The keyboard is easily warped or damaged during the removal process. Take care not to use excessive force when removing to prevent damage.

1. See “Removing the Battery Pack” on page 37.
2. See “Removing the Base Door” on page 39.
3. See “Removing the DIMM Module” on page 42.
4. See “Removing the WLAN Module” on page 43.
5. See “Removing the 2nd HDD Module” on page 45.
6. See “Removing the ODD Module” on page 48.
7. Remove the twenty two (22) screws in the lower cover.



| Step                    | Screw                        | Quantity | Screw Type   |
|-------------------------|------------------------------|----------|--|
| Lower Cover Disassembly | M2.5*6.0 (red callouts)      | 22       |  |
|                         | M2.5*2L(NI) (green callouts) | 2        |   |


8. Using plastic tweezers, release the six (6) clips holding the keyboard in place.




9. Gently pry up the keyboard.



10. Carefully flip the keyboard over.




11. Detach the keyboard FCC and remove the keyboard.




## Removing the Upper Cover

1. See "Removing the Keyboard" on page 52.
2. Disconnect the power board FFC.



3. Unlock and disconnect the touchpad board FFC.






4. Unlock and disconnect the speaker cable.





5. Remove the seven (7) screws from the upper cover.




| Step                    | Screw                   | Quantity | Screw Type  |
|-------------------------|-------------------------|----------|---|
| Upper Cover Disassembly | 2.5*4.0 (red callouts)  | 6        |  |
|                         | 2.0*3.0 (green callout) | 1        |  |

6. Lift the upper cover away from the lower cover as shown.




## Removing the LCD Module


1. See "Removing the Upper Cover" on page 54
2. Pull the WLAN antenna up through the upper cover and free it from the cable channel.




3. Using the pull tab, release the LVDS cable from the connector.




4. Remove the four (4) screws from the hinges.



| Step              | Screw    | Quantity | Screw Type   |
|-------------------|----------|----------|--|
| Remove LCD Module | M2.5*6.0 | 4        |  |


5. Remove the LCD module from the chassis.

**CAUTION:** Make sure all cables are pulled back and away from the device to avoid damage during removal.





# Removing the Bluetooth Module

- 1. See "Removing the Upper Cover" on page 54.
- 2. Disconnect the Bluetooth cable from the mainboard..




- 3. Remove the one (1) screw from the Bluetooth module.




| Step                         | Screw  | Quantity | Screw Type.  |
|------------------------------|--------|----------|--|
| Bluetooth Module Disassembly | M2.5*3 | 1        |  |

- 4. Lift the Bluetooth module away from the upper cover.




- 
5. Detach the Bluetooth module cable from the module.




## Removing the USB Board

1. See “Removing the Upper Cover” on page 54.
2. Unlock the USB board connector and disconnect the cable from the mainboard.




3. Peel the cable off the adhesive.





**IMPORTANT:** Take care not to tear the FFC pull tab during removal.

4. Unlock the USB board cable connector and disconnect the cable from the board.




5. Remove one (1) screw from the USB board.





| Step                   | Screw | Quantity | Screw Type.  |
|------------------------|-------|----------|--|
| USB Module Disassembly | 2.5*6 | 1        |  |

6. Lift the USB board clear of the chassis.




## Removing the Mainboard


1. See "Removing the Upper Cover" on page 54.
2. Disconnect the following cables (a,b) from the mainboard.






3. Remove three (3) screws from the mainboard.




| Step                   | Screw  | Quantity | Screw Type.  |
|------------------------|--------|----------|--|
| Main Board Disassembly | M2.5*6 | 2        |  |


4. Lift the mainboard out of the chassis as shown.




# Removing the LAN Board

- 1. See "Removing the Mainboard" on page 62.
- 2. Remove two (2) screws from the LAN board.



| Step                   | Screw    | Quantity | Screw Type.  |
|------------------------|----------|----------|--|
| LAN Module Disassembly | M2.5*6.0 | 2        |  |


- 3. Lift the LAN board clear of the chassis.



---

## Removing the RTC Battery

1. See “Removing the Mainboard” on page 62.
2. Pull the RTC battery off the mainboard.




**NOTE:** The RTC battery has been highlighted with the yellow circle as shown in the previous image. Please detach the RTC battery and follow local regulations for disposal.


---

## Removing the Thermal Module


1. See "Removing the Mainboard" on page 62.
2. Disconnect the thermal module fan connector.



3. Loosen the six (6) captive screws from the thermal module.




- 
4. Lift the thermal module away from the main board.




---

## Removing the CPU

1. See “Removing the Thermal Module” on page 66.
2. Unlock the CPU. Use a flathead screw driver to turn the screw 180°.




3. Lift the CPU out of the socket.





# Removing the PCH Heatsink


1. See "Removing the Mainboard" on page 62.
2. Loosen the two (2) captive screws.



3. Lift the thermal unit away.



| Step                      | Screw    | Quantity | Screw Type.  |
|---------------------------|----------|----------|--|
| Removing the PCH Heatsink | M2.5*6.0 | 2        |  |




**NOTE:** Circuit boards >10 cm<sup>2</sup> have been highlighted with a yellow rectangle as shown in the previous image. Please detach the circuit board and follow local regulations for disposal.




---

## Removing the DC-IN Cable Assembly

1. See “Removing the Mainboard” on page 62.
2. See “Removing the Upper Cover” on page 54.
3. Remove the DC-IN cable from the retention guides.




4. Lift the DC-IN cable assembly out of the chassis.







## Removing the Switch Board

1. See "Removing the Upper Cover" on page 54.
2. Remove the two (2) screws.




| Step                     | Screw    | Quantity | Screw Type  |
|--------------------------|----------|----------|---|
| Switch Board Disassembly | M2.5*2Ni | 2        |  |

3. Lift the switch board away from the upper cover (1) and turn it over (2).





- 
4. Unlock and disconnect the switch board FFC.




---


## Removing the Power Board

1. See "Removing the Upper Cover" on page 54.
2. Unlock and disconnect the power board FFC.




3. Remove the three (3) screws.



| Step                    | Screw | Quantity | Screw Type  |
|-------------------------|-------|----------|---|
| Power Board Disassembly | 2.0*3 | 3        |  |

4. Lift the power board away.




# LCD Module Disassembly Process

**IMPORTANT:** Cable paths and positioning may not represent the actual model. During the removal and replacement of components, ensure all available cable channels and clips are used and that the cables are replaced in the same position.

**NOTE:** The product previews seen in the disassembly procedures may not represent the final product color or configuration.

## LCD Module Disassembly Flowchart




### Screw List

| Step                    | Screw | Quantity | Part No. |
|-------------------------|-------|----------|----------|
| LCD Bezel Disassembly   |       |          |          |
| LCD Panel Disassembly   |       |          |          |
| Left Hinge Disassembly  |       |          |          |
| Right Hinge Disassembly |       |          |          |

# Removing the LCD Bezel

- 1. See "Removing the Upper Cover" on page 54.
- 2. Remove the two (2) screws from the LCD bezel as shown.




| Step                   | Screw | Quantity | Screw Type.  |
|------------------------|-------|----------|--|
| Removing the LCD Bezel | 2.5*4 | 2        |  |

- 3. Pry the bezel away from the top-center and then work around until the entire bezel is detached.




- 
4. Remove the bezel from the LCD module.




---

## Removing the Camera Board

1. See "Removing the LCD Bezel" on page 76.
2. Pull up the camera board.



3. Disconnect the camera connector.






---


## Removing the LCD Panel

1. See "Removing the LCD Bezel" on page 76.
2. Remove the six (6) screws from the LCD panel.




| Step                  | Screw | Quantity | Screw Type   |
|-----------------------|-------|----------|--|
| LCD Panel Disassembly | 2.5*4 | 6        |  |


3. Remove LVDS cable from cable guides




4. Disconnect the microphone cable.




5. Lift the LCD panel out.



6. Remove 6 screws from the LCD brackets (3 on each side).




| Step                    | Screw | Quantity | Screw Type   |
|-------------------------|-------|----------|--|
| LCD Bracket Disassembly | 2.5*4 | 6        |  |


- 
7. Separate the brackets from the panel as shown.



8. Peel the LVDS cable off the panel.




9. Continue peeling the cable off the LCD panel.




10. Peel back the mylar tape and disconnect the LVDS cable.



11. Remove the adhesive foil tabs covering the microphone cable.




12. Lift up the microphone cable and remove it from the LCD cover.




---

## Removing the Antennas


1. See "Removing the LCD Panel" on page 79.
2. Remove the antenna cables from the retention guides.




3. Free the cables completely.



4. Pry the left antenna from the casing.



- 
5. Pry the right antenna from the casing.




---


# LCD Reassembly Procedure

## Replacing the Microphone

1. Lay the microphone cable in the LCD cover and replace the adhesive foil tabs.




2. Replace the microphone.




---

## Replacing the Antennas

1. See See “Replacing the Microphone” on page 85.
2. Adhere the left antenna down firmly onto the LCD module casing.






3. Adhere the right antenna down firmly onto the LCD module casing.






- 
4. Lay the cables around the module edge.




---

## Replacing the LCD Panel


1. See “Replacing the Antennas” on page 86.
2. Connect the FPC cable connector.




3. Place the protective clear adhesive mylar tape down firmly over the connector.



4. Continue adhering the webcam cable to the LCD panel.




5. Adhere the webcam cable to the back of the LCD panel, in parallel with the panel edges.




6. Replace the brackets to the panel as shown.



7. Replace the six (6) screws to the LCD brackets (3 on each side).




8. Replace the LCD panel into the top cover.



9. Replace the six (6) screws to the LCD panel.




10. Connect the microphone cable.



---


11. Place the LVDS cable into cable guides




---

## Replacing the Camera Board

1. See "Replacing the LCD Panel" on page 88.
2. Connect the cable to the Camera Board.



3. Lay the Camera board down and press firmly to apply the adhesive.



---

## Replacing the LCD Bezel


1. See “Replacing the Camera Board” on page 92.
2. Place the bezel hinge covers over the hinges. Ensure the cables are correctly exiting the hinges.



3. Press down on the top middle edge of the bezel to engage the locking clips.



4. Press down on the bezel edge working simultaneously around the edges to the bottom.



- 
5. Replace the two (2) bezel screws.






---


# Main Unit Reassembly Process

## Replacing the Power Assembly

6. Place the DC jack into the lower cover.




7. Lay the cables in the retention guides.




---

## Replacing the PCH Thermal Module

1. Place the PCH thermal module on the PCH chip.




2. Replace the two (2) screws.




## Replacing the CPU

**IMPORTANT:** The CPU has a Pin1 locator that must be positioned corresponding to the marker on the CPU socket.

1. Place the CPU into the CPU socket as shown, taking note of the Pin1 locator.



- 
- Using a flat-bladed screw driver, rotate the CPU locking screw 180° clockwise to secure the CPU in place.



# Replacing the Thermal Module

**IMPORTANT:** Apply a suitable thermal grease and ensure all heat pads are in place before replacing the Thermal Module.



The following thermal grease types are approved for use:

- Silmore GP50
- Honeywell
- Jet Motor 7762


The following thermal pads are approved for use:

- Eapus XR-PE

1. See “Replacing the CPU” on page 96.
2. Remove all traces of thermal grease from the CPU using a lint-free cloth or cotton swab and Isopropyl Alcohol, Acetone, or other approved cleaning agent.
3. Apply a small amount of thermal grease to the centre of the CPU—there is no need to spread the grease manually, the force used during the installation of the Thermal Module is sufficient.
4. Align the screw holes on the Thermal Module and Mainboard then replace the module. Keep the module as level as possible to spread the thermal grease evenly.
5. Replace the six (6) securing screws to secure the Thermal Module in place.




6. Connect the fan cable.



---

## Replacing the RTC Battery


1. Push the RTC battery into the cradle on the mainboard, plus (+) side up.




---

## Removing the LAN Board

1. Line up the screw holes, then replace the LAN board onto the mainboard.




2. Replace the two (2) screws.




---

## Replacing the Main Board

1. See “Replacing the Power Assembly” on page 95.
2. See “Replacing the PCH Thermal Module” on page 96.
3. See “Replacing the CPU” on page 96.
4. See “Replacing the Thermal Module” on page 98.
5. See “Replacing the RTC Battery” on page 99.
6. See “Removing the LAN Board” on page 100.
7. Slide the main board external connector edge in first to the lower case, then lower into place.




8. Replace the three (3) screws to secure the mainboard to the lower cover.



---

9. Connect the CD-IN connector.







---

## Replacing the USB board


1. See “Replacing the Main Board” on page 101.
2. Place the USB board into the lower case edge first.




3. Replace the one (1) screw.




4. Adhere the USB board FFC to the chassis.



5. Connect and lock the USB board FFC to the USB board.




6. Connect and lock the USB board FFC to the mainboard.




---

## Replacing the Bluetooth Module


1. See “Replacing the Main Board” on page 101.
2. Connect the Bluetooth cable to the Bluetooth module.




3. Place the Bluetooth module onto the mainboard pressing down firmly.



4. Replace the one (1) screw.




- 
5. Connect the Bluetooth module cable to the main board.



---

## Replacing the LCD Module


1. See “Replacing the Main Board” on page 101.
2. Place the LCD module hinges into position on the lower case.




3. Replace the four (4) screws, two each in the left and right hinges.




4. Insert the antenna cables through the lower cover and pull through from the other side.



- 
5. Lay the LVDS cable across the assembly as shown and press down firmly.




6. Connect the LVDC cable.




---

# Replacing the Power Board


1. Place the power board into the upper cover.



2. Replace the three (3) screws.




3. Connect and lock the FFC.




---

# Replacing the Switch Board


1. Connect and lock the FFC.



2. Turn the switch board over and place into the upper cover.



3. Replace the two (2) screws.






---

## Replacing the Upper Cover


1. See “Replacing the Main Board” on page 101.
2. See “Replacing the LCD Module” on page 107.
3. See “Replacing the Bluetooth Module” on page 105.
4. See “Replacing the USB board” on page 103.
5. See “Replacing the Power Board” on page 109.
6. See “Replacing the Switch Board” on page 110.
7. Place the upper cover onto the lower cover aligning the hinges first and then press down around the edges.




8. Replace the seven (7) screws.



9. Turn the computer over and replace the twenty (24) screws on the bottom cover.




10. Connect the speaker cable.




---

11. Connect and lock the Switch Board FFC.




12. Connect and lock the Power board FFC.



---

## Replacing the Keyboard

1. See “Replacing the Upper Cover” on page 111.
2. Connect and lock the FFC to the mainboard.




3. Turn the keyboard over and insert the bottom edge in first, then push to down ensure the five latches across the top are fully secured.




---

## Replacing the Wireless LAN Module


1. See “Replacing the Keyboard” on page 114.
2. Insert the wireless LAN module into the connector.



3. Replace the one screw.




4. Replace the connectors. The white (Aux) cable attaches to the connector marked **2** on the board. The black (Main) cable attaches to the connector marked **1** on the board.




---

## Replacing the DIMM Module

1. See “Replacing the Keyboard” on page 114.
2. Slide the DIMM module into the connector.




3. Press down till the locking springs click into place.



---

## Replacing the 2nd HDD Module


1. See “Replacing the Keyboard” on page 114.
2. Replace the HDD bracket.




3. Replace the four (4) screws.



4. Place the HDD into the lower cover.



- 
5. Replace the HDD cover.



6. Replace the one (1) screw.







---

## Replacing the Hard Disk Drive


1. See "Replacing the Keyboard" on page 114.
2. Place the HDD bracket onto the HDD.



3. Replace the two (2) screws.



4. Insert the HDD into the bay inserting the bracket flanges into the lower cover slot first.



- 
5. Grasp the tab and slide the HDD firmly into the docking connector.




---

## Replacing the ODD Module

1. See "Replacing the Keyboard" on page 114.
2. Replace the ODD bezel.




3. Replace the ODD bracket.



4. Replace the two (2) screws of the ODD bracket.




- 
5. Push the ODD completely into the bay until flush with the lower cover.




---

## Replacing the Base Door


1. See “Replacing the Wireless LAN Module” on page 115.
2. See “Replacing the DIMM Module” on page 116.
3. See “Replacing the Hard Disk Drive” on page 119.
4. See “Replacing the ODD Module” on page 121.
5. Insert the base door edge flanges into the slots.



6. Lower the base door.




7. Tighten the six (6) screws.



---

## Replacing the Battery

1. See “Replacing the Base Door” on page 123.
2. Slide the battery into position.



3. Close the locking latch.



## Replace the Dummy Card

Push the dummy card into the slot until it clicks into place.



# Troubleshooting

---

## Common Problems

Use the following procedure as a guide for computer problems.

**NOTE:** The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.

1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
3. Use the following table with the verified symptom to determine which page to go to.


| Symptoms (Verified)         | Go To    |
|-----------------------------|----------|
| Power On Issue              | Page 126 |
| No Display Issue            | Page 127 |
| LCD Failure                 | Page 129 |
| Internal Keyboard Failure   | Page 130 |
| TouchPad Failure            | Page 131 |
| Internal Speaker Failure    | Page 132 |
| Internal Microphone Failure | Page 133 |
| USB Failure                 | Page 135 |
| Other Function Failure      | Page 135 |

4. If the Issue is still not resolved, see "Online Support Information" on page 157.

---

## Power On Issue

If the system doesn't power on, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



## Computer Shuts down Intermittently


If the system powers off at intervals, perform the following actions one at a time to correct the problem.

1. Check the power cable is properly connected to the computer and the electrical outlet.
2. Remove any extension cables between the computer and the outlet.
3. Remove any surge protectors between the computer and the electrical outlet. Plug the computer directly into a known good electrical outlet.
4. Remove all external and non-essential hardware connected to the computer that are not necessary to boot the computer to the failure point.
5. Remove any recently installed software.
6. If the Issue is still not resolved, see "Online Support Information" on page 157.



# No Display Issue

If the **Display** doesn't work, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



## No POST or Video

If the POST or video doesn't display, perform the following actions one at a time to correct the problem.

1. Make sure that the internal display is selected. On this notebook model, switching between the internal display and the external display is done by pressing **Fn+F5**. Reference Product pages for specific model procedures.
2. Make sure the computer has power by checking at least one of the following occurs:
  - Fans start up
  - Status LEDs light up

If there is no power, see "Power On Issue" on page 126.

3. Drain any stored power by removing the power cable and battery and holding down the power button for 10 seconds. Reconnect the power and reboot the computer.
4. Connect an external monitor to the computer and switch between the internal display and the external display is by pressing **Fn+F5** (on this model).

If the POST or video appears on the external display, see "LCD Failure" on page 129.

5. Disconnect power and all external devices including port replicators or docking stations. Remove any memory cards and CD/DVD discs. Restart the computer.

---

If the computer boots correctly, add the devices one by one until the failure point is discovered.

6. Reseat the memory modules.
7. Remove the drives (see “Disassembly Process” on page 35).
8. If the Issue is still not resolved, see “Online Support Information” on page 157.

## Abnormal Video Display

If video displays abnormally, perform the following actions one at a time to correct the problem.

1. Reboot the computer.
2. If permanent vertical/horizontal lines or dark spots display in the same location, the LCD is faulty and should be replaced. See “Disassembly Process” on page 35.
3. If extensive pixel damage is present (different colored spots in the same locations on the screen), the LCD is faulty and should be replaced. See “Disassembly Process” on page 35.
4. Adjust the brightness to its highest level. See the User Manual for instructions on adjusting settings.  
**NOTE:** Ensure that the computer is not running on battery alone as this may reduce display brightness.

If the display is too dim at the highest brightness setting, the LCD is faulty and should be replaced. See “Disassembly Process” on page 35.

5. Check the display resolution is correctly configured:
  - a. Minimize or close all Windows.
  - b. If display size is only abnormal in an application, check the view settings and control/mouse wheel zoom feature in the application.
  - c. If desktop display resolution is not normal, right-click on the desktop and select **Personalize**→ **Display Settings**.
  - d. Click and drag the Resolution slider to the desired resolution.
  - e. Click **Apply** and check the display. Readjust if necessary.
6. Roll back the video driver to the previous version if updated.
7. Remove and reinstall the video driver.
8. Check the Device Manager to determine that:
  - The device is properly installed. There are no red Xs or yellow exclamation marks.
  - There are no device conflicts.
  - No hardware is listed under Other Devices.
9. If the Issue is still not resolved, see “Online Support Information” on page 157.
10. Run the Windows Memory Diagnostic from the operating system DVD and follow the onscreen prompts.
11. If the Issue is still not resolved, see “Online Support Information” on page 157.

## Random Loss of BIOS Settings

If the computer is experiencing intermittent loss of BIOS information, perform the following actions one at a time to correct the problem.

1. If the computer is more than one year old, replace the CMOS battery.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. If the computer is experiencing HDD or ODD BIOS information loss, disconnect and reconnect the power and data cables between devices.


If the BIOS settings are still lost, replace the cables.

4. If HDD information is missing from the BIOS, the drive may be defective and should be replaced.
5. Replace the Motherboard.

6. If the Issue is still not resolved, see "Online Support Information" on page 157.

## LCD Failure


If the **LCD** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



---

## Built-In Keyboard Failure


If the built-in **Keyboard** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



---

## TouchPad Failure


If the **TouchPad** doesn't work, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



---

# Internal Speaker Failure

If the internal **Speakers** fail, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



## Sound Problems

If sound problems are experienced, perform the following actions one at a time to correct the problem.


1. Reboot the computer.
2. Navigate to **Start** → **Control Panel** → **System and Maintenance** → **System** → **Device Manager**. Check the Device Manager to determine that:
  - The device is properly installed.
  - There are no red Xs or yellow exclamation marks.
  - There are no device conflicts.
  - No hardware is listed under Other Devices.
3. Roll back the audio driver to the previous version, if updated recently.
4. Remove and reinstall the audio driver.
5. Ensure that all volume controls are set mid range:
  - a. Click the volume icon on the taskbar and drag the slider to 50. Ensure that the volume is not muted.
  - b. Click Mixer to verify that other audio applications are set to 50 and not muted.
6. Navigate to **Start** → **Control Panel** → **Hardware and Sound** → **Sound**. Ensure that Speakers are selected as the default audio device (green check mark).

**NOTE:** If Speakers does not show, right-click on the **Playback** tab and select **Show Disabled Devices** (clear by default).
7. Select Speakers and click **Configure** to start **Speaker Setup**. Follow the onscreen prompts to configure the speakers.
8. Remove and recently installed hardware or software.

9. Restore system and file settings from a known good date using **System Restore**.  
If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
10. Reinstall the Operating System.
11. If the Issue is still not resolved, see “Online Support Information” on page 157.

## Internal Microphone Failure

If the internal **Microphone** fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



## Microphone Problems

If internal or external **Microphones** do not operate correctly, perform the following actions one at a time to correct the problem.

1. Check that the microphone is enabled. Navigate to **Start** → **Control Panel** → **Hardware and Sound** → **Sound** and select the **Recording** tab.
2. Right-click on the **Recording** tab and select **Show Disabled Devices** (clear by default).
3. The microphone appears on the **Recording** tab.
4. Right-click on the microphone and select **Enable**.
5. Select the microphone then click **Properties**. Select the **Levels** tab.
6. Increase the volume to the maximum setting and click **OK**.
7. Test the microphone hardware:
  - a. Select the microphone and click **Configure**.
  - b. Select **Set up microphone**.
  - c. Select the microphone type from the list and click **Next**.
  - d. Follow the onscreen prompts to complete the test.

- 
8. If the Issue is still not resolved, see “Online Support Information” on page 157.

## HDD Not Operating Correctly

If the **HDD** does not operate correctly, perform the following actions one at a time to correct the problem.

1. Disconnect all external devices.
2. Run a complete virus scan using up-to-date software to ensure the computer is virus free.
3. Run the Windows 7 Startup Repair Utility:
  - a. insert the Windows 7 Operating System DVD in the ODD and restart the computer.
  - b. When prompted, press any key to start to the operating system DVD.
  - c. The **Install Windows** screen displays. Click **Next**.
  - d. Select **Repair your computer**.
  - e. The **System Recovery Options** screen displays. Click **Next**.
  - f. Select the appropriate operating system, and click **Next**.

**NOTE:** Click **Load Drivers** if controller drives are required.

- g. Select **Startup Repair**.
- h. Startup Repair attempts to locate and resolve issues with the computer.
- i. When complete, click **Finish**.

If an issue is discovered, follow the onscreen information to resolve the problem.

4. Run the Windows Memory Diagnostic Tool. For more information see Windows Help and Support.
5. Restart the computer and press F2 to enter the BIOS Utility. Check the BIOS settings are correct and that CD/DVD drive is set as the first boot device on the Boot menu.
6. Ensure all cables and jumpers on the HDD and ODD are set correctly.
7. Remove any recently added hardware and associated software.
8. Run the Windows Disk Defragmenter. For more information see Windows Help and Support.
9. Run Windows Check Disk by entering **chkdsk /r** from a command prompt. For more information see Windows Help and Support.
10. Restore system and file settings from a known good date using **System Restore**.


If the issue is not fixed, repeat the preceding steps and select an earlier time and date.
11. Replace the HDD. See “Disassembly Process” on page 35.



---

## USB Failure (Right up/down side)

If the rightside **USB** port fails, perform the following actions one at a time to correct the problem. Do not replace non-defective FRUs:



## Other Failures

If the VGA board, LAN Port, external MIC or Speakers, PCI Express Card, 5-in-1 Card Reader or Volume Wheel fail, perform the following general steps to correct the problem. Do not replace non-defective FRUs:

1. Check whether the drive is OK.
2. Verify that the Test Fixture is OK.
3. Swap the mainboard and retest.

---

# Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the system board in loop mode at least 10 times.
2. If no error is detected, do not replace any FRU.
3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

# Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.

Follow these procedures to isolate the failing FRU (do not isolate non-defective FRU).

**NOTE:** Verify that all attached devices are supported by the computer.

**NOTE:** Verify that the power supply being used at the time of the failure is operating correctly. (See “Power On Issue” on page 126.):

1. Power-off the computer.
2. Visually check them for damage. If any problems are found, replace the FRU.
3. Remove or disconnect all of the following devices:
  - Non-Acer devices
  - Printer, mouse, and other external devices
  - Battery pack
  - Hard disk drive
  - DIMM
  - CD-ROM/Diskette drive Module
  - PC Cards
4. Power-on the computer.
5. Determine if the problem has changed.
6. If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
7. If the problem remains, replace the following FRU one at a time. Do not replace a non-defective FRU:
  - System board
  - LCD assembly

# Post Code Reference Tables

These tables describe the POST codes and descriptions during the POST.

## Post Code Range

| Phase                    | POST Code Range |
|--------------------------|-----------------|
| SEC                      | 0x01 - 0x0F     |
| PEI                      | 0x70 - 0x9F     |
| DXE                      | 0x40 - 0x6F     |
| BDS                      | 0x10 - 0x3F     |
| SMM                      | 0xA0 - 0xBF     |
| S3                       | 0xC0 - 0xCF     |
| ASL                      | 0x51 – 0x55     |
|                          | 0xE1 – 0xE4     |
| PostBDS                  | 0xF9 – 0xFE     |
| InsydeH2ODDT™<br>Reserve | 0xD0 – 0xD7     |
| OEM Reserve              | 0xE8 – 0xEB     |
| Reserved                 | 0xD8 – 0xE0     |
|                          | 0xE5 – 0xE7     |
|                          | 0xEC – 0xF8     |

## SEC Phase POST Code Table

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description                               |
|--|-------|-----------|---|
| SEC_SYSTEM_POWER_ON                      | SEC   | 1         | CPU power on and switch to Protected mode |
| SEC_BEFORE_MICROCODE_PATCH               | SEC   | 2         | Patching CPU microcode                    |
| SEC_AFTER_MICROCODE_PATCH                | SEC   | 3         | Setup Cache as RAM                        |
| SEC_ACCESS_CSR                           | SEC   | 4         | PCIE MMIO Base Address initial            |
| SEC_GENERIC_MSRINIT                      | SEC   | 5         | CPU Generic MSR initialization            |
| SEC_CPU_SPEEDCFG                         | SEC   | 6         | Setup CPU speed                           |
| SEC_SETUP_CAR_OK                         | SEC   | 7         | Cache as RAM test                         |
| SEC_FORCE_MAX_RATIO                      | SEC   | 8         | Tune CPU frequency ratio to maximum level |
| SEC_GO_TO_SECSTARTUP                     | SEC   | 9         | Setup BIOS ROM cache                      |
| SEC_GO_TO_PEICORE                        | SEC   | 0A        | Enter Boot Firmware Volume                |

## PEI Phase POST Code Table:

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description                       |
|--|-------|-----------|-----------------------------------|
| PEI_SIO_INIT                             | PEI   | 70        | Super I/O Initialization          |
| PEI_CPU_REG_INIT                         | PEI   | 71        | CPU Early Initialization          |
| PEI_PCIE_MMIO_INIT                       | PEI   | 74        | PCIE MMIO BAR Initialization      |
| PEI_NB_REG_INIT                          | PEI   | 75        | North Bridge Early Initialization |
| PEI_SB_REG_INIT                          | PEI   | 76        | South Bridge Early Initialization |
| PEI_TPM_INIT                             | PEI   | 78        | TPM Initialization                |
| PEI_SMBUS_INIT                           | PEI   | 79        | SMBUS Early Initialization        |

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description                                  |
|--|-------|-----------|--|
| PEI_PROGRAM_CLOCK_GEN                    | PEI   | 7A        | Clock Generator Initialization               |
| PEI_IGD_EARLY_INITIAL                    | PEI   | 7B        | Internal Graphic device early Initialization |
| PEI_HECI_INIT                            | PEI   | 7C        | HECI Initialization                          |
| PEI_WATCHDOG_INIT                        | PEI   | 7D        | Watchdog timer Initialization                |
| PEI_MEMORY_INIT                          | PEI   | 7E        | Memory Initial for Normal boot.              |
| PEI_MEMORY_INIT_FOR_CRISIS               | PEI   | 7F        | Memory Initial for Crisis Recovery           |
| PEI_MEMORY_INSTALL                       | PEI   | 80        | Simple Memory test                           |
| PEI_TXTPEI                               | PEI   | 81        | TXT function early Initialization            |
| PEI_SWITCH_STACK                         | PEI   | 82        | Start to use Memory                          |
| PEI_MEMORY_CALLBACK                      | PEI   | 83        | Set cache for physical memory                |
| PEI_ENTER_RECOVERY_MODE                  | PEI   | 84        | Recovery device Initialization               |
| PEI_RECOVERY_MEDIA_FOUND                 | PEI   | 85        | Found Recovery image                         |
| PEI_RECOVERY_MEDIA_NOT_FOUND             | PEI   | 86        | Recovery image not found                     |
| PEI_RECOVERY_LOAD_FILE_DONE              | PEI   | 87        | Load Recovery Image completed                |
| PEI_RECOVERY_START_FLASH                 | PEI   | 88        | Start Flash BIOS with Recovery image         |
| PEI_ENTER_DXEIPL                         | PEI   | 89        | Loading BIOS image to RAM                    |
| PEI_FINDING_DXE_CORE                     | PEI   | 8A        | Loading DXE core                             |
| PEI_GO_TO_DXE_CORE                       | PEI   | 8B        | Enter DXE core                               |

**DXE Phase POST Code Table:**

| Functionality Name (Include\ PostCode.h) | Phase | PostCode | Description                             |
|--|-------|----------|---|
| DXE_TCGDXE                               | DXE   | 40       | TPM initial in DXE                      |
| DXE_SB_SPI_INIT                          | DXE   | 41       | South bridge SPI initialization         |
| DXE_CF9_RESET                            | DXE   | 42       | Setup Reset service                     |
| DXE_SB_SERIAL_GPIO_INIT                  | DXE   | 43       | South bridge Serial GPIO initialization |
| DXE_SMMACCESS                            | DXE   | 44       | Setup SMM ACCE SS service               |
| DXE_SIO_INIT                             | DXE   | 46       | Super I/O DXE initialization            |
| DXE_LEGACY_REGION                        | DXE   | 47       | Setup Legacy Region service             |
| DXE_IDENTIFY_FLASH_DEVICE                | DXE   | 49       | Identify Flash device                   |
| DXE_FTW_INIT                             | DXE   | 4A       | Fault Tolerant Write verification       |
| DXE_VARIABLE_INIT                        | DXE   | 4B       | Variable Service initialization         |
| DXE_VARIABLE_INIT_FAIL                   | DXE   | 4C       | Fail to initial Variable Service        |
| DXE_MTC_INIT                             | DXE   | 4D       | MTC Initial                             |
| DXE_CPU_INIT                             | DXE   | 4E       | CPU Middle Initialization               |
| DXE_MP_CPU_INIT                          | DXE   | 4F       | Multi-processor MiddleInitialization    |
| DXE_SMBUS_INIT                           | DXE   | 50       | SMBUS Driver Initialization             |
| DXE_SMART_TIMER_INIT                     | DXE   | 51       | 8259 Initialization                     |
| DXE_PCRTC_INIT                           | DXE   | 52       | RTC Initialization                      |

| Functionality Name (Include PostCode.h) | Phase | PostCode | Description                              |
|---|-------|----------|--|
| DXE_SATA_INIT                           | DXE   | 53       | SATA Controller earlyInitialization      |
| DXE_SMM_CONTROLLER_INIT                 | DXE   | 54       | Setup SMM Control service                |
| DXE_LEGACY_INTERRUPT                    | DXE   | 55       | Setup Legacy Interrupt service           |
| DXE_RELOCATE_SMBASE                     | DXE   | 56       | Relocate SMM BASE                        |
| DXE_FIRST_SMI                           | DXE   | 57       | SMI test                                 |
| DXE_VTD_INIT                            | DXE   | 58       | VTD Initial                              |
| DXE_BEFORE_CSM16_INIT                   | DXE   | 59       | Legacy BIOS Initialization               |
| DXE_AFTER_CSM16_INIT                    | DXE   | 5A       | Legacy interrupt function Initialization |
| DXE_LOAD_ACPI_TABLE                     | DXE   | 5B       | ACPI Table Initialization                |
| DXE_SB_DISPATCH                         | DXE   | 5C       | Setup SB SMM Dispatcher service          |
| DXE_SB_IOTRAP_INIT                      | DXE   | 5D       | Setup SB IOTRAP Service                  |
| DXE_SUBCLASS_DRIVER                     | DXE   | 5E       | Build AMT Table                          |
| DXE_PPM_INIT                            | DXE   | 5F       | PPM Initialization                       |
| DXE_HECIDRV_INIT                        | DXE   | 60       | HECIDRV Initialization                   |

**BDS Phase POST Code Table:**

| Functionality Name (Include PostCode.h) | Phase | Post Code | Description  |
|---|-------|-----------|--|
| BDS_ENTER_BDS                           | BDS   | 10        | Enter BDS entry  |
| BDS_INSTALL_HOTKEY                      | BDS   | 11        | Install Hotkey service                                 |
| BDS_ASF_INIT                            | BDS   | 12        | ASF Initialization                                     |
| BDS_PCI_ENUMERATION_START               | BDS   | 13        | PCI enumeration  |
| BDS_BEFORE_PCIO_INSTALL                 | BDS   | 14        | PCI resource assign complete                           |
| BDS_PCI_ENUMERATION_END                 | BDS   | 15        | PCI enumeration complete                               |
| BDS_CONNECT_CONSOLE_IN                  | BDS   | 16        | Keyboard Controller, Keyboard and Mouse initialization |
| BDS_CONNECT_CONSOLE_OUT                 | BDS   | 17        | Video device initialization                            |
| BDS_CONNECT_STD_ERR                     | BDS   | 18        | Error report device initialization                     |
| BDS_CONNECT_USB_HC                      | BDS   | 19        | USB host controller initialization                     |
| BDS_CONNECT_USB_BUS                     | BDS   | 1A        | USB BUS driver initialization                          |
| BDS_CONNECT_USB_DEVICE                  | BDS   | 1B        | USB device driver initialization                       |
| BDS_NO_CONSOLE_ACTION                   | BDS   | 1C        | Console device initial fail                            |
| BDS_DISPLAY_LOGO_SYSTEM_INFO            | BDS   | 1D        | Display logo or system information                     |
| BDS_START_IDE_CONTROLLER                | BDS   | 1E        | IDE controller initialization                          |
| BDS_START_SATA_CONTROLLER               | BDS   | 1F        | SATA controller initialization                         |
| BDS_START_ISA_ACPI_CONTROLLER           | BDS   | 20        | SIO controller initialization                          |
| BDS_START_ISA_BUS                       | BDS   | 21        | ISA BUS driver initialization                          |
| BDS_START_ISA_FDD                       | BDS   | 22        | Floppy device initialization                           |
| BDS_START_ISA_SEIRAL                    | BDS   | 23        | Serial device initialization                           |
| BDS_START_IDE_BUS                       | BDS   | 24        | IDE device initialization                              |
| BDS_START_AHCI_BUS                      | BDS   | 25        | AHCI device initialization                             |

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description                                    |
|--|-------|-----------|--|
| BDS_CONNECT_LEGACY_ROM                   | BDS   | 26        | Dispatch option ROMs                           |
| BDS_ENUMERATE_ALL_BOOT_OPTION            | BDS   | 27        | Get boot device information                    |
| BDS_END_OF_BOOT_SELECTION                | BDS   | 28        | End of boot selection                          |
| BDS_ENTER_SETUP                          | BDS   | 29        | Enter Setup Menu                               |
| BDS_ENTER_BOOT_MANAGER                   | BDS   | 2A        | Enter Boot manager                             |
| BDS_BOOT_DEVICE_SELECT                   | BDS   | 2B        | Try to boot system to OS                       |
| BDS_EFI64_SHADOW_ALL_LEGACY_ROM          | BDS   | 2C        | Shadow Misc Option ROM                         |
| BDS_ACPI_S3SAVE                          | BDS   | 2D        | Save S3 resume required data in RAM            |
| BDS_READY_TO_BOOT_EVENT                  | BDS   | 2E        | Last Chipset initial before boot to OS         |
| BDS_GO_LEGACY_BOOT                       | BDS   | 2F        | Start to boot Legacy OS                        |
| BDS_GO_UEFI_BOOT                         | BDS   | 30        | Start to boot UEFI OS                          |
| BDS_LEGACY16_PREPARE_TO_BOOT             | BDS   | 31        | Prepare to Boot to Legacy OS                   |
| BDS_EXIT_BOOT_SERVICES                   | BDS   | 32        | Send END of POST Message to ME via HECI        |
| BDS_LEGACY_BOOT_EVENT                    | BDS   | 33        | Last Chipset initial before boot to Legacy OS. |
| BDS_ENTER_LEGACY_16_BOOT                 | BDS   | 34        | Ready to Boot Legacy OS.                       |
| BDS_RECOVERY_START_FLASH                 | BDS   | 35        | Fast Recovery Start Flash.                     |

**PostBDS POST Code Table**

| Functionality Name (Include\ PostCode.h) | Phase    | Post Code | Description             |
|--|----------|-----------|-------------------------|
| POST_BDS_NO_BOOT_DEVICE                  | POST_BDS | F9        | No Boot Device          |
| POST_BDS_START_IMAGE                     | POST_BDS | FB        | UEFI Boot Start Image   |
| POST_BDS_ENTER_INT19                     | POST_BDS | FD        | Legacy 16 boot entry    |
| POST_BDS_JUMP_BOOT_SECTOR                | POST_BDS | FE        | Try to Boot with INT 19 |

**S3 Functions POST Code Table**

| Functionality Name (Include\ PostCode.h) | Phase    | Post Code | Description             |
|--|----------|-----------|-------------------------|
| POST_BDS_NO_BOOT_DEVICE                  | POST_BDS | F9        | No Boot Device          |
| POST_BDS_START_IMAGE                     | POST_BDS | FB        | UEFI Boot Start Image   |
| POST_BDS_ENTER_INT19                     | POST_BDS | FD        | Legacy 16 boot entry    |
| POST_BDS_JUMP_BOOT_SECTOR                | POST_BDS | FE        | Try to Boot with INT 19 |

**ACPI Functions POST Code Table**

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description         |
|--|-------|-----------|---------------------|
| ASL_ENTER_S1                             | ASL   | 51        | Prepare to enter S1 |
| ASL_ENTER_S3                             | ASL   | 53        | Prepare to enter S3 |

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description           |
|--|-------|-----------|-----------------------|
| ASL_ENTER_S4                             | ASL   | 54        | Prepare to enter S4   |
| ASL_ENTER_S5                             | ASL   | 55        | Prepare to enter S5   |
| ASL_WAKEUP_S1                            | ASL   | E1        | System wakeup from S1 |
| ASL_WAKEUP_S3                            | ASL   | E3        | System wakeup from S3 |
| ASL_WAKEUP_S4                            | ASL   | E4        | System wakeup from S4 |

**SMM Functions POST Code Table**

| Functionality Name (Include\ PostCode.h) | Phase | Post Code | Description                    |
|--|-------|-----------|--------------------------------|
| SMM_IDENTIFY_FLASH_DEVICE                | SMM   | 0xA0      | Identify Flash device in SMM   |
| SMM_SMM_PLATFORM_INIT                    | SMM   | 0xA2      | SMM service initial            |
| SMM_ACPI_ENABLE_START                    | SMM   | 0xA6      | OS call ACPI enable function   |
| SMM_ACPI_ENABLE_END                      | SMM   | 0xA7      | ACPI enable function complete  |
| SMM_S1_SLEEP_CALLBACK                    | SMM   | 0xA1      | Enter S1                       |
| SMM_S3_SLEEP_CALLBACK                    | SMM   | 0xA3      | Enter S3                       |
| SMM_S4_SLEEP_CALLBACK                    | SMM   | 0xA4      | Enter S4                       |
| SMM_S5_SLEEP_CALLBACK                    | SMM   | 0xA5      | Enter S5                       |
| SMM_ACPI_DISABLE_START                   | SMM   | 0xA8      | OS call ACPI disable function  |
| SMM_ACPI_DISABLE_END                     | SMM   | 0xA9      | ACPI disable function complete |

**InsydeH2ODDT Debugger POST Code Table**

| Functionality Name (Include\ PostCode.h) | PostCode | Description  |
|--|----------|--|
| Used by Insyde debugger                  | 0x0D     | Waiting for device connect                         |
| Used by Insyde debugger                  | 0xD0     | Waiting for device connect                         |
| Used by Insyde debugger                  | 0xD1     | InsydeH2ODDT Ready                                 |
| Used by Insyde debugger                  | 0xD2     | EHCI not found                                     |
| Used by Insyde debugger                  | 0xD3     | Debug port connect low speed device                |
| Used by Insyde debugger                  | 0xD4     | DDT Cable become low speed device                  |
| Used by Insyde debugger                  | 0xD5     | DDT Cable Transmission Error (Get descriptor fail) |
| Used by Insyde debugger                  | 0xD6     | DDT Cable Transmission Error (Set Debug mode fail) |
| Used by Insyde debugger                  | 0xD7     | DDT Cable Transmission Error (Set address fail)    |





# Jumper and Connector Locations

---

## Mainboard Top View

| Item | Description | Item | Description |
|------|-------------|------|-------------|
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |

---

## Mainboard Bottom View

| Item | Description | Item | Description |
|------|-------------|------|-------------|
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |
|      |             |      |             |

---

# Clearing Password Check and BIOS Recovery

This section provides a procedure for clearing the password and BIOS. The Hardware Open Gap on the main board clears the CMOS of all user settings and restores factory defaults.

## Mainboard CMOS Discharge

Discharging the CMOS clears all user settings.

1. Disassemble the notebook and take out the 2nd HDD. See “Removing the 2nd HDD Module” on page 45.
2. Remove the RTC battery. See “Removing the RTC Battery” on page 65.

TBD - Check this with Charles

3. Turn the mainboard over and short the G2 pad.

4. Reconnect the RTC battery and reassemble the unit.

---

# BIOS Recovery by Crisis Disk

## BIOS Recovery Boot Block

The BIOS Recovery Boot Block is a special block of BIOS. It is used to boot up the system with minimum BIOS initialization. Users can enable this feature to restore the BIOS firmware to the factory settings if a BIOS flash process fails.

## BIOS Recovery Hotkey

The system provides a function hotkey: **Fn+Esc**, to enable the BIOS Recovery process when a system is powered on during BIOS POST. To use this function, it is strongly recommended to have the AC adapter and Battery present. If this function is enabled, the system will force the BIOS to enter a special BIOS block, called Boot Block.

## Steps for BIOS Recovery from USB Storage

Before performing this procedure, prepare a Crisis USB key. The Crisis USB key can be made by executing the Crisis Disk program in a functioning system with a Windows 7 OS.

**IMPORTANT:**The Crisis Disk program will overwrite all data on any drive that you use as a crisis disk.

Follow the steps below:

1. Modify the archive name from " "
2. Save ROM file (file name: ) to the root directory of the USB storage.
3. Plug the USB storage into a USB port.
4. Press **Fn + ESC** button then plug in AC.  
The Power button flashes once.
5. Press **Power** button to initiate system CRISIS mode.  
When CRISIS is complete, the system auto restarts with a workable BIOS.
6. Update the latest version BIOS for this machine by the regular BIOS flashing process.

# FRU (Field Replaceable Unit) List

---

This chapter gives you the FRU (Field Replaceable Unit) listing in global configurations of the computer. Refer to this chapter whenever ordering for parts to repair or for RMA (Return Merchandise Authorization).

Please note that WHEN ORDERING FRU PARTS, you should check the most up-to-date information available on your regional web or channel. For whatever reasons a part number change is made, it will not be noted on the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code from those given in the FRU list of this printed Service Guide. You MUST use the local FRU list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

**NOTE:** To scrap or to return the defective parts, you should follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.

## Exploded Diagrams

---

# Main Assembly

| Item | Description | Part Number |
|------|-------------|-------------|
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |

---

| Item | Description | Part Number |
|------|-------------|-------------|
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |

**NOTE:** Part numbers may be different depending on your model. Please refer to the FRU List for a full listing of part numbers.

---

# LCD Assembly

| Item | Description | Part Number |
|------|-------------|-------------|
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |
|      |             |             |

**NOTE:** Part numbers may be different depending on your model. Please refer to the FRU List for a full listing of part numbers.



---

FRU List

Screw Table



# Model Definition and Configuration

---



# Test Compatible Components

---

This computer's compatibility is tested and verified by Acer's internal testing department. All of its system functions are tested under Windows® 7 environment.

Refer to the following lists for components, adapter cards, and peripherals which have passed these tests. Regarding configuration, combination and test procedures, please refer to the Compatibility Test Report released by the Acer Mobile System Testing Department.



# Online Support Information

---

This section describes online technical support services available to help you repair your Acer Systems.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer Branch Offices and Regional Business Units may access our website. However some information sources will require a user i.d. and password. These can be obtained directly from Acer CSD Taiwan.

Acer's Website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all of Acer's Notebook, Desktop and Server models including:

- Service guides for all models
- User's manuals
- BIOS updates
- Software utilities
- Spare parts lists
- TABs (Technical Announcement Bulletin)

For these purposes, we have included an Acrobat File to facilitate the problem-free downloading of our technical material.

Also contained on this website are:

- Detailed information on Acer's International Traveler's Warranty (ITW)
- Returned material authorization procedures
- An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.





**A**

- Antennas
  - Removing 83, 86

**B**

- Battery Pack
  - Removing 37
- BIOS
  - ROM type 15
  - vendor 15
- BIOS Utility 19–27
  - Advanced 22
  - Boot 25
  - Exit 26
  - Navigating 19
  - Power 25
  - Save and Exit 26
  - Security 22
  - System Security 26
- brightness
  - hotkeys 12

**C**

- Camera Board
  - Removing 78, 92
- caps lock
  - on indicator 8
- Common Problems 126
- CPU
  - Replacing 96
- CRT Cable
  - Removing 62

**D**

- DIMM Module
  - Removing 42
- Display 4
- display
  - hotkeys 12

**E**

- Euro Key 13
- External Module Disassembly
  - Flowchart 36

**F**

- Features 1
- FLASH Utility 27
- Flash Utility 27
- FRU (Field Replaceable Unit) List 147

**H**

- Hard Disk Drive Module
  - Removing 40
- Hibernation mode
  - hotkey 12
- Hot Keys 10

**I**

- Indicators 8
- Intermittent Problems 136
- Internal Microphone Failure 133
- Internal Speaker Failure 132

**J**

- Jumper and Connector Locations 143

**K**

- Keyboard
  - Removing 52
- Keyboard Failure 130

**L**

- LCD Bezel
  - Removing 76, 93
- LCD Failure 129
- LCD Module
  - Removing 107
- LCD Module Disassembly
  - Flowchart 75
- LCD Panel
  - Removing 79

**M**

- Main Unit Disassembly
  - Flowchart 50

---

Mainboard  
    Removing 62  
media access  
    on indicator 8  
Memory Check 126  
Microphone  
    Removing 79  
Model Definition 153

## N

No Display Issue 127  
num lock  
    on indicator 8

## O

ODD Failure 135  
Online Support Information 157

## P

Panel 5  
PC Card 8  
Power On Failure 126

## S

Speaker Module  
    Removing 58  
speakers  
    hotkey 12  
System  
    Block Diagram 4

## T

Test Compatible Components 155  
Thermal Module  
    Removing 66  
Touch Pad Failure 131  
TouchPad FFC  
    Removing 60, 64, 100  
Troubleshooting  
    Built-in KB Failure 130  
    Internal Microphone 133  
    Internal Speakers 132  
    LCD Failure 129  
    No Display 127  
    ODD 135  
    Other Failures 135

Power On 126  
Touch Pad 131  
USB 135

## U

Undetermined Problems 136  
Upper Cover  
    Removing 54  
USB Failure (Rightside) 135  
utility  
    BIOS 19–27

## V

volume  
    hotkeys 12

## W

Windows 2000 Environment Test 155  
WLAN Board  
    Removing 43